Schweizer Parts and Tooling List
FOR SALE
All offers welcome

email katrina.amiria@salusaviation.com

BREAKDOWN OF THE CONDITION OF THE PARTS
76% NEW
11% INSPECTED
7% OVERHAULED
5% SERVICEABLE
2% AS REMOVED

Please refer to the Salus Aviation Schweizer Helicopter Parts and Tooling Package Terms and Conditions at the back of this document.

Product Code	Description	Qty	Condition
473450	SEAL	2	NE
132035A	SPRAG CLUTCH	1	SV
2-016N507-90	O-RING (M21628697)	2	NE
269A1205-1.223	SPACER PITCH BEARING CASE GROUND TO 1.223"	7	NE
269A1205-1.224	SPACER PITCH BEARING CASE GROUND TO 1.224"	5	NE
269A1205-1.225	SPACER PITCH BEARING CASE GROUND TO 1.225"	5	NE
269A1205-1.226	SPACER	4	NE
269A1205-1.227	SPACER	5	NE
269A1205-804	SPACER, PITCH BEARING 1.2230" +.0005-.0000	9	NE
269A1205-804	SPACER, PITCH BEARING 1.2230" +.0005-.0000	2	NE
269A1205-805	SPACER, PITCH BEARING 1.2240" +.0005-.0000	9	NE
269A1205-805	SPACER, PITCH BEARING 1.2240" +.0005-.0000	2	NE
269A1205-806	SPACER, PITCH BEARING 1.2250" +.0005-.0000	9	NE
269A1205-806	SPACER, PITCH BEARING 1.2250" +.0005-.0000	2	NE
269A1206	SLEEVE PITCH BEARING CASE	3	IN
269A1209	WASHER THRUST MAIN ROTOR	4	IN
269A1209-BSC	THRUST WASHER M/R FLAPPING HGE	6	IN
269A1209-BSC	THRUST WASHER M/R FLAPPING HGE	17	NE
269A1219-005	SLEEVE-BEARING	3	NE
269A1230	RETAINER	2	IN
269A1245	CAP	4	IN
269A1257	BEARING M/R BLADE DAMPER	2	NE
269A1263-003	WASHER	2	NE
269A1271	PLATE ASSY M/R BLADE DAMPER	1	NE
269A1301	BEARING ASSY	1	NE
269A1307	SEAL, MAIN ROTOR	2	NE
269A1310-005	BOOT SWASHPLATE GUIDE TUBE TOP	2	NE
269A1315	NUT M/R THRUST BEARING	2	IN
269A1315	NUT M/R THRUST BEARING	2	NE
269A1318-003	TUBE	1	SV
269A1318-005	TUBE M/R THRUST BRG	2	IN
269A1320	RETAINER PLATE.DROOP STOP RING	2	IN
269A1324	LINER SWASHPLATE SLEEVE ASSY	2	NE
269A1328-025	SUPPORT ASSY	3	IN
269A1330-009	PLATE, M/R LOWER SWASHPLATE	1	SV
269A1333-013	SWASHPLATE - UPPER	2	IN
269A1333-013	SWASHPLATE - UPPER	1	NE
269A1335-007	LINK ASSY - SWASH PLATE UPR SC	1	IN
269A1336	LINK ASSY SWASH PLT	2	IN
269A1336	LINK ASSY SWASH PLT	1	NE

Product Code	Description	Qty	Condition
269A1338	ROD ASSEMBLY	6	IN
269A1340	NUT	1	IN
269A1340-003	NUT DROOP STOP RING RETAINER	4	NE
269A1341	DEFLECTOR	2	NE
269A1354	BOLT SPECIAL M/R HUB	4	IN
269A1354	BOLT SPECIAL M/R HUB	1	NE
269A1356-005	WASHER	2	NE
269A1358	SHIM WASHER	3	NE
269A1928	SPACER	6	NE
269A1929	SHIM M/R BLADE DAMPER	2	NE
269A2025-001	FITTING TAIL BOOM SUPPORT STRUT	1	NE
269A2288-003	STRIKER DOOR -LATCH	1	NE
269A2309	GROMMET	1	NE
269A2329-175	RETAINER	2	NE
269A2330-005	DAMPER ASSY TAIL BOOM	1	NE
269A3108-BSC	BOOT LANDING-GEAR DAMPER	1	NE
269A3150-005	UNDERCARRIAGE DAMPER, FWD	1	OH
269A3150-007	DAMPER ASSY	1	AR
269A3150-021	DAMPER ASSY AFT	2	OH
269A3150-800	UNDER CARRIGE KIT	6	NE
269A3150-801	DAMPER OVERHAUL KIT	1	NE
269A3152-001	CAP ASSY.LANDING GEAR DAMPER	1	NE
269A3154	CAP LANDING GEAR DAMPER (LWR)	1	NE
269A3155	PLUG. LANDING-GEAR DAMPER	1	NE
269A3156-003	HOUSING ASSEMBLY, POPPET	5	OH
269A3156-003	HOUSING ASSEMBLY, POPPET	3	SV
269A3161	SPRING, LANDING-GEAR DAMPER	8	NE
269A3161	SPRING, LANDING-GEAR DAMPER	2	OH
269A3162-003	PISTON - DAMPER, L/G	17	AR
269A3162-005	PISTON-DAMPER. L/G	3	NE
269A3163-003	BARREL	5	OH
269A3163-011	BARREL	1	OH
269A3166	WASHER LANDING-GEAR DAMPER	8	NE
269A3167-003	BAFFLE	7	NE
269A3168	SPRING	3	OH
269A3169-001	PLATE L/G DAMPENER	8	NE
269A3170-001	CAP LANDING GEAR DAMPER	1	NE
269A3230-002L	SLEEVE. SKID. R/H	1	NE
269A3231L	SLEEVE	3	NE
269A4030-003	BOOT.T/R PEDAL ARM	2	NE

Product Code	Description	Qty	Condition
269A4031-003	BOOT. COLLECTIVE STICK	5	NE
269A4067-003	PATCH	2	NE
269A4093-807	BRACKET INST'L SPARES ONLY	1	NE
269A4298-009	STUD. BATTERY INSTALLATION	2	NE
269A4337	SPACER	2	NE
269A4507-005	TUBE, PLASTIC - BATTERY INSTALLATION	3	NE
269A4611	SWITCH THERMAL GEAR	1	IN
269A4619-013	SHAFT ASSY. ROTOR TACH	1	NE
269A4646-205	DECAL, "LUB SAE90"	2	NE
269A4897-901	CONTROL ASSEMBLY SPARES	2	NE
269A4951-003	HEAD SET-JACK ASSY	2	NE
269A4985-009	ALTERNATOR CONTROL UNIT	2	NE
269A5050-018	BEARING T/R PITCH CONTROL	1	IN
269A5050-018	BEARING T/R PITCH CONTROL	1	NE
269A5050-020	BEARING LANDING-GEAR STRUT	1	NE
269A5050-024	BEARING	12	NE
269A5050-027	BEARING	4	NE
269A5050-039	BEARING SPHERICAL GREASE LUBE	1	NE
269A5050-040	BEARING SPHERICAL GREASE LUBE	2	NE
269A5050-042	BRG	2	NE
269A5050-043	BEARING SPHERICAL M/R DAMPER	2	NE
269A5050-058	BEARING	5	NE
269A5050-061	BEARING SPHERICAL M/R DAMPER	3	NE
269A5050-063	BEARING M/R DRIVE SHAFT	1	NE
269A5050-071	BEARING FLAPPING HINGE	7	SV
269A5050-076	BEARING ROD ASSEMBLY	5	NE
269A5050-090	BEARING	1	NE
269A5050-091	BEARING T/R PITCH LINK RPLCS -075	1	NE
269A5050-100	BEARING	2	NE
269A5051-009	CUP, M/R TRANSMISSION	2	NE
269A5051-010	CONE, M/R TRANSMISSION	2	NE
269A5051-019	BEARING	1	NE
269A5104-007	GEAR, RING, M/R TRANSMISSION	1	NE
269A5106-003	SHAFTGEAR/T/R TX	2	NE
269A5115	SLEEVE PINION FWD	1	NE
269A5119	GASKET M/R TRANSMISSION	2	NE
269A5120	RETAINER, M/R TRANSMISSION	1	OH
269A5121	GASKET	2	NE
269A5124	SPACER. M/R XMSN	2	NE
269A5132	OIL PUMP ASSEMBLY	2	OH

Product Code	Description	Qty	Condition
269A5140	GASKET M/R TRANSMISSION	1	NE
269A5141	PUMP GEAR DRIVE SHAFT. M/R TRA	1	NE
269A5144	WASHER, PUMPSHAFT, M/R TRANS	2	NE
269A5149-001	BEARING RETAINER NUT	4	NE
269A5150	WASHER. PINION. M/R TRANSMISSI	1	NE
269A5150	WASHER. PINION. M/R TRANSMISSI	1	OH
269A5178-013	COLLAR PINION OIL SEAL	1	NE
269A5178-017	COLLAR - PINION OIL SEAL	5	NE
269A5181	NOZZLE, M/R TRANSMISSION	1	OH
269A5181	NOZZLE, M/R TRANSMISSION	2	SV
269A5182-7	CASE, UPPER	1	AR
269A5182-7	CASE, UPPER	1	OH
269A5186	BUSHING. M/R TRANSMISSION	2	NE
269A5187-BSC	GASKET M/R TRANSMISSION	6	NE
269A5190-007	OVERHAUL KIT, M/R TRANSMISSION	1	NE
269A5190-013	OVERHAUL KIT. M/R TRANSMISSION	1	NE
269A5197	VALVE & CHIP (DETECTOR)	1	NE
269A5198-001	SEAL	3	NE
269A5209-001	SIGHT GAGE M/R TRANSMISSION	1	SV
269A5212-001	HOUSING ASSY, LOWER	1	OH
269A5410-003	SHIM BELT DRIVE	1	NE
269A5421-3	UPPER PULLEY	2	SV
269A5473	BOOT	1	NE
269A5486-003	WASHER CLUTCH CONTROL	1	NE
269A5498-005	SHAFT	1	AR
269A5512-5	BELT SET	3	NE
269A5519-013	BRACKET ASSEMBLY. BELT DRIVE	3	NE
269A5558	RING RETAINER	6	NE
269A5580	RETAINER	2	NE
269A5583	SHAFT BELT DRIVE	1	NE
269A5623	RETAINER ASSEMBLY, T/R TRANSMISSION	3	OH
269A5648-003	BREATHER T/R TRANSMISSION	1	SV
269A5654-005	HOUSING	1	NE
269A5655-003	DECAL-OIL LEVER PLUG	1	NE
269A5666	RETAINER ASSEMBLY, T/R TRANSMISSION	3	OH
269A6028	SPACER T/R GEARBOX	2	NE
269A6029	NUT DRIVEN SPLINE T/R GEARBOX	1	NE
269A6029	NUT DRIVEN SPLINE T/R GEARBOX	1	SV
269A6031-BSC	SEAL NUT TAILROTOR	1	NE
269A6050-007	HOUSING ASSEMBLY	1	OH

Product Code	Description	Qty	Condition
269A6062-007	BEARING T/R	2	NE
269A6063-009	T/R GEARBOX SEAL	5	NE
269A6082	SWAGE RING PITCH CONTROL BRG	1	NE
269A6091-005	LINK ASSEMBLY T/R ASSEMBLY	2	NE
269A6094	BUSHING	1	NE
269A6095-005	WASHER.T/R ASSY	2	NE
269A6095-007	WASHER.T/R ASSY	2	NE
269A6095-011	WASHER TAIL ROTOR DRIVE	1	NE
269A6095-11	TEETER BOLT , WASHER	1	NE
269A6102-009	BOOT ROTATING- TAIL ROTOR	1	NE
269A6102-009	BOOT T/R	1	NE
269A6246	PIN TAIL ROTOR	1	NE
269A7004	CAP	6	NE
269A7118-BSC	DISC CYCLIC PITCH	3	NE
269A7138-003	WORM. GEAR ASSY. LATERAL CONTR	1	NE
269A7143-BSC	WASHER CYCLIC PITCH	3	NE
269A7195	BUSHING, LONGITUDINAL CONTROL	1	NE
269A7214-005	DISC COLLECTIVE STICK	1	NE
269A7214-007	DISC COLLECTIVE STICK	1	NE
269A7216	DISC	1	NE
269A7221	WASHER	1	NE
269A8174-007	HOSE AIR INTAKE	2	NE
269A8323	GASKET, FUEL TANK	100	NE
269A8379-013	HOSE ASSEMBLY. AUXILIARY FUEL	1	NE
269A8430	BRACKET	3	NE
269A8437	BUSHING THROTTLE	4	NE
269A8500-119	DIPSTICK ASSY 269C	3	NE
269A8506-007L	80-SHIM	2	NE
269A8517-800	1.00 SCAT DUCT (BLAST TUBE)	1	NE
269A8578	GASKET	1	NE
269A8596	BRACKET ASSY	2	NE
269A8605	ABSORBER INNER	10	IN
269A8616-BSC	SPACER	3	NE
269A9410-001	FUEL QUANTITY PROBE ASSY	2	NE
269A9533-001	CONTROL UNIT - AES/STRT-UP LIMTR/LRW	1	NE
269D5312-007	COLLET - M/R HUB & SHAFT	2	IN
269D5312-007	COLLET - M/R HUB & SHAFT	3	NE
269D5312-009	COLLET SET - M/R HUB & SHAFT	2	IN
269D5312-009	COLLET SET - M/R HUB & SHAFT	2	NE
269D5313-005	NUT	2	IN

Product Code	Description	Qty	Condition
269D5314-003	WASHER	1	IN
269D5314-005	WASHER-MAIN ROTOR DRIVE, SPLINED	2	NE
269D9292-001	LIFT EYE	1	IN
269D9292-001	LIFT EYE	2	NE
26S51-6	STUD.CAMLOC M28603710	1	NE
26S51-9	FASTENER (M28603712)	2	NE
3080-00038	SENDER. CHT	2	NE
79325-428	NUT (M22609076)	2	NE
79380	BOOT (M21810119)	1	NE
9800-0002	SENDER M31605954	1	NE
A8189	BOLT & BREATHER AIR VENT ASSEMBLY	1	NE
AN3CH7A	BOLT	2	NE
BA5405	FILTER ELEMENT.M30801320	2	NE
D1119	GEAR	2	NE
HSCR00032	BUSHING SLOTTED SHS626-4-313	2	NE
K3822	DISTRIBUTOR BLOCK	2	NE
M21017550	GASKET	1	NE
M21625973	2-034-47-071 PACKING	4	NE
M22606743	FN22M624 NUT	4	NE
M27606350	SHS306-231H WASHER	1	NE
M27607071	W-02 LOCK WASHER	2	NE
MS21254-3LL	EYE (M21202053)	13	NE
N02	SCHWEIZER	5	NE
NAS1304-54D	BOLT	3	IN
NAS1308-55D	BOLT	1	NE
NAS1922-0225-1H	CLAMP	2	NE
NAS427K8	PIN	2	NE
RR268	RING (M21209392)	8	NE
RSN118	SNAP RING	1	NE
RSN118	SNAP RING	5	NE
S51PB	SIGHT GLASS	1	SV
SL60W9	LOCK WASHER	1	NE
SL61N9F	LOCK NUT	2	IN
SL61W9F	WASHER	2	NE
SUP-504-3052	END CAP	7	NE
SUP-504-6512	5" DISC	7	NE

Equipment Description	Part Number
PIN, BALANCE ADAPTER, SCHWEIZER 269	
269 MGB Lockwasher install	
269 Pitch Case Journal Measuring Mount	
269C Lower Driveshaft - Boot Install	
MGB Breather removal	
269 Piston Spanner	
269 U/C Cylinder Holding Blocks	34005877
269 Barrel identification tool	
269 M/R Trans Bushing Removal Tool	-
M/R Blade Tab Angle Measuring Tool + Tab Bending Tool	11365-1 & 11452-2
Upper Pulley Bearing Puller (3 pieces)	
Bearing Press Tool (3 parts)	
MGB Pressing Tool - roller bearing	
MGB Pattern Rig 269	
Pitch Shaft Straightening Jig	
Seal Installer	
Holding Fixture and Spanner	
Holding Fixture	
Lock	
Holding Fixture	
Setting Tool	
Holding Fixture	
Socket 1 7/8	
Wrench Extension	
Bonding Fixture	
MGB Spline Socket - vice mount	
Wrench C Main	
Backlash Holding Set	
1/8 Allen Socket	
Holding Tool	
Upper Carrier BRG Clamp Ring	
Mount	
269 U/C Damper Pilot Tool	269A3162-3 MT-1-1
Pitch Shaft Master	
Upper Pulley Bearing Removal Tool	

Equipment Description	Part Number
0-1000 psi 1/4 BSP/NPT BOTTOM ENTRY GAUGE	Teltherm
0-4" DTI Mitutoyo (Load stroke test kit)	3428S-19
Load Cell 1200 Series (Load stroke test kit)	1210AJ-5K-B
Tail Rotor Driveshaft Grease Tool (fwd)	
Tail Rotor Driveshaft Grease Tool (aft)	
Tail Rotor Transmission Coupling Socket	
Droop Stop Spanner	269T9321
Main Rotor Thrust Nut Spanner	269T9312
2 x Upper Pulley Pressing Tool	269T3321
Upper Pulley Socket	
Upper Pulley Torque Tool	
Upper Pulley Holding Fixture	269T3320
Droop Stop Nut Tool	269T9231
Wrench Splined Fitting	269T9281
T/R Locknut Wrench	
M/R Damper Rig Tramel	
M/R Damper Rig Tramel	
M/R Flapping Hinge Wrench	
M/R Flapping Hinge Wrench	
M/R Hub Nut Socket	
M/R Trans Pinion Nut Socket	
Alignment Lower Coupling Tool	
M/R Rigg Block	269T9272-1
T/R Swash Plate	269T9204-3
T/R Rigging Tool	269T9286
Longitudinal Rigging Tool	269T9203-7
Lateral Rigging Tool	269T9269

Salus Aviation Schweizer Helicopter Parts and Tooling Package Terms and Conditions:
Salus Aviation (AW) Ltd, is seeking offers to purchase the Schweizer parts and tooling package. This is an invitation to treat and not an offer to sell. Potential purchasers are invited to submit an offer to purchase from the parts and tooling package listed. Offers are to be exclusive of GST. Salus Aviation reserves the right to accept or reject any offer and is not obligated to accept the highest offer. Priority will be given to offers for the entire package. All parts remain for sale during this package promotion and accordingly the package is subject to change. In the event of any change to the offered parts and tooling package, Salus Aviation will provide an affected offeror the option to resubmit their offer. Any sales will be on Salus Aviation's standard terms and conditions. Parts and tooling will be delivered "ex works" at Salus Aviation's premises at Ardmore Airport. If an offer is accepted, the parts and tooling are sold as is and without any warranty, payment will be required in advance and no credit terms will apply. Once paid, the Purchaser shall be responsible for freight and insurance.